



Â

Soldering is required. You get everything you need to build a 30 amp

First you build the circuit board kit. Then with a few hand tools you put together this 16 ch

Â

